

# CROSS REFERENCES LIST 2006

Old code	New code	Parts description
4031.003	4031.329	SIMEL COUPLING
4031.007	4032.453	AIR REGULATION FLAP
4031.031	4111.134	NOZZLE
4031.050	4031.197	FUEL PUMP
4031.051	4031.197	FUEL PUMP
4031.085	4111.040	FUSE 10A
4031.088	4111.119	SOCKET
4031.089	4111.118	PLUG
4031.091	4031.095	ELECTRODE
4031.097	4110.971	H T CABLE
4031.145	4110.962	FUEL CAP
4031.170	4160.637	SWITCH "MAN-AUT"
4031.205	4031.338	ELECTRODE
4031.215	4032.454	NUT M6
4031.271	4162.065	FAN
4031.408	4161.432	HOSE BINDER
4031.716	4031.071	FILTER
4031.720	4031.045	SAFETY THERMOSTAT
4031.739	4031.047	OVERHEAT THERMOSTAT
4031.741	4031.906	NOZZLE
4032.100	4031.120	OIL PRE-HEATER
4032.108	4111.119	THERMOSTAT PLUG
4100.562	4110.080	MOTOR
4100.633	4100.663	NOZZLE ADAPTER
4100.642	4110.136	FUEL TANK
4100.643	4110.140	FUEL TANK
4100.644	4100.630	FUEL FILTER
4100.651	4110.079	MOTOR
4100.652	4110.080	MOTOR
4100.655	4110.132	IGNITOR KIT
4100.665	4110.142	PC-BOARD ASSY
4100.672	4110.032	TUBE
4100.676	4110.142	PC-BOARD HSI
4101.854	4100.648	NOZZLE
4103.553	4515.003	ROTOR KIT B 35 / B 150
4103.554	4515.004	ROTOR KIT B 70 / B 100
4103.556	4515.013	FILTER KIT B 100 / B 150
4103.561	4515.012	AIR FILTER KIT B 30 / B 70
4103.651	4100.662	FAN 35 / 70 CED / CEL
4103.659	4103.695	FAN GUARD
4104.097	4110.032	FUELLINE TUBE
4104.113	4100.630	FUEL FILTER
4104.121	4110.147	FUELLINE TUBE

## CROSS REFERENCES LIST 2006

Old code	New code	Parts description
4105.296	4110.140	FUEL TANK
4105.508	4109.567	FUELLINE TUBE
4106.098	4110.042	MOTOR
4106.122	4110.070	PLUG BUTTON
4108.544	4108.619	SCREW
4109.736	4109.716	FILTER LINT
4110.081	4110.132	IGNITOR
4110.084	4103.289	WHELL 2 PCS
4110.085	4108.429	CAP NUT
4110.097	4110.079	MOTOR
4110.148	4104.156	AIR LINE TUBE
4110.163	4110.124	SCREW 4,8X13
4110.184	4104.147	TUBING RUBBER FUEL LINE
4110.186	4101.240	BRACKET MOTOR
4110.188	4100.673	KIT GROUND SCREW W/NUT
4110.189	4108.494	KIT HANDLE SCREW W/NUT
4110.516	4110.132+.142	IGNITER + PC BOARD
4110.964	4111.134	NOZZLE
4111.237	4110.966	PHOTOCELL
4114.500	4031.906	NOZZLE
4116.559	4116.599	ELECTRODE MINI VAL
4117.139	4111.081	PUMP COUPLING
4117.143	4031.070	FUEL FILTER
4117.144	4031.015	FILTER ELEMENT
4117.145	4111.116	FILTER KIT
4150.260	4515.901+.902	COUPLING SET
4150.615	4510.601	HANDLE
4150.616	4160.636	SAFETY THERMOSTAT+CLIP
4150.617	4162.243	MOTOR
4150.618	4160.629	MOTOR
4150.619	4160.630	MOTOR
4150.620	4160.958	MOTOR
4150.621	4161.049	FAN
4150.622	4160.690	FAN
4150.624	4160.959	FAN
4150.626	4160.733	ELECTRIC CABLE
4150.635	4160.637+.638	SWITCH M/A
4150.647	4160.655	ELECTRO VALVE
4150.648	4160.963	ELECTRO VALVE
4150.656	4161.139	END FITTING
4150.667	4161.103	GAS NOZZLE
4150.668	4160.722	GAS NOZZLE
4150.672	4161.046	ELECTRODE

## CROSS REFERENCES LIST 2006

Old code	New code	Parts description
4150.674	4161.138	THERMOCOUPLE
4150.676	4160.687	GASBURNER
4150.678	4160.676	GASBURNER
4150.679	4160.701	RING NUT
4150.680	4161.102	PILOT FLAME
4150.696	4111.118	PLUG 4 PIN
4150.698	4161.139	END FITTING
4150.708	4160.661	GAS HOSE
4150.716	4160.685	REGULATOR
4150.761	4160.731	ELECTRODE
4150.762	4162.222	PIEZO IGNITOR
4150.889	4160.656	GAS TUBE
4160.102	4510.410	PLUG
4160.103	4510.411	PLUG
4160.200	4161.368	KNOB
4160.456	4100.654	PC BOARD SUPPORT
4160.640	4162.222	ADAPTER FOR PIEZO IGNITOR
4160.641	4162.222	PIEZO IGNITOR
4160.642	4160.731	IGNITION ELECTRICAL FOLDER
4160.653	4161.137	SAFETY GAS VALVE
4160.688	4161.137	SAFETY GAS VALVE
4160.715	4510.601	PLASTIC HANDLE
4161.045	4160.731	ELECTRODE
4161.059	4161.248	ELECTRODE
4161.184	4110.142	PC BOARD
4161.331	4510.301	MOTOR
4162.069	4031.095	ELECTRODE
4162.071	4031.047	OVERHEAT THERMOSTAT
4162.090	4111.119	SOCKET
4162.091	4111.118	PLUG
4162.098	4031.133	WHEEL
4162.102	4160.638	SWITCH PROFILE
4165.007	4510.610	KNOB
4165.008	4510.612	RESET LEVER
4165.009	4510.611	TEMP LIMITER SUPPORT
4165.010	4510.405	TEMP LIMITER
4165.011	4510.403	THERMOSTAT
4165.012	4510.401	SWITCH
4165.014	4510.312	FAN
4165.016	4510.407	POWER CORD
4165.019	4510.607	SUPPORT
4165.020	4510.404	OVERHEAT SENSOR
4165.022	4510.405	TEMP LIMITER

# CROSS REFERENCES LIST 2006

Old code	New code	Parts description
4165.023	4510.362	ELEMENT
4165.024	4510.408	POWER CORD
4165.029	4510.416	THERMOSTAT
4165.031	4510.359	ELEMENT
4165.032	4510.302	ELECTRIC MOTOR
4165.035	4510.402	RELAY
4165.045	4510.360	ELEMENT
4165.046	4510.313	FAN
4165.047	4510.303	ELECTRIC MOTOR
4165.057	4510.355	ELEMENT
4165.058	4510.314	FAN
4165.186	4510.356	ELEMENT
4165.188	4111.032	RELAY
4165.190	4510.412	PLUG
4506.201	4506.120	SPEALING CORD
4510.352	4510.359	ELEMENT
4510.354	4510.360	ELEMENT
4510.406	4510.410	PLUG 16A
4510.417	4111.032	RELAY

A „New code“ replace a „Old code“

In ordering, please use “New code”