


MASTER ELECTRIC HEATERS

MODEL B 2 IT

ILLUSTRATED PARTS BREAKDOWN




MASTER ELECTRIC HEATERS B 2 IT

Pos.	Description	Code NR
1	TOP COVER	4165.000
2	CONTROL BASE	4165.001
3	DEFLECTOR	4165.002
4	SIDE PANELS	4165.003
5	FRONT PANEL	4165.004
6	GRILL	4165.005
7	BOTTOM PANEL	4165.006
8	KNOB	4165.007
9	RESET LEVER	4165.008
10	TEMP LIMITER SUPPORT	4165.009
11	TEMP LIMITER	4165.010
12	THERMOSTAT	4165.011
13	SWITCH	4165.012
14	ELEMENT	4165.013
15	FAN	4165.014
16	ELECTRIC MOTOR	4161.331
17	POWER CORD	4165.016
18	CABLE RELIEF	4165.017
19	HANDLE	4160.715
20	SUPPORT	4165.019
21	OVERHEAT SENSOR	4165.020

MASTER ELECTRIC HEATERS

MODEL B 3 IT

ILLUSTRATED PARTS BREAKDOWN




MASTER ELECTRIC HEATERS B 3 IT

Pos.	Description	Code NR
1	COVER	4165.000
2	CONTROL BASE	4165.001
3	DEFLECTOR	4165.002
4	SIDE PANELS	4165.003
5	FRONT PANEL	4165.021
6	GRILL	4165.005
7	BOTTOM PANEL	4165.006
8	KNOB	4165.007
9	RESET LEVER	4165.008
10	TEMP LIMITER SUPPORT	4165.009
11	TEMP LIMITER	4165.022
12	THERMOSTAT	4165.011
13	SWITCH	4165.012
14	ELEMENT	4165.023
15	FAN	4165.014
16	ELECTRIC MOTOR	4161.331
17	POWER CORD	4165.024
18	CABLE RELIEF	4165.017
19	HANDLE	4160.715
20	SUPPORT	4165.019
21	OVERHEAT SENSOR	4165.020

MASTER ELECTRIC HEATERS

MODEL B 5 IT

ILLUSTRATED PARTS BREAKDOWN




MASTER ELECTRIC HEATERS B 5 IT

Pos.	Description	Code NR
1	TOP COVER	4165.025
2	CONTROL BASE	4165.026
3	DEFLECTOR	4165.002
4	SIDE PANELS	4165.027
5	FRONT PANEL	4165.028
6	GRILL	4165.005
7	BOTTOM PANEL	4165.006
8	KNOB	4165.007
9	RESET LEVER	4165.008
10	TEMP LIMITER SUPPORT	4165.009
11	TEMP LIMITER	4165.010
12	THERMOSTAT	4165.029
13	SWITCH	4165.030
14	ELEMENT	4165.031
15	FAN	4165.014
16	ELECTRIC MOTOR	4165.032
17	HANDLE	4165.033
18	PLUG	4160.102
19	RELAY	4165.035
20	RUBBER SUPPORT	4165.036
21	SEPARATOR	4165.037
22	OVERHEAT SENSOR	4165.020

MASTER ELECTRIC HEATERS

MODEL B 9 IT

ILLUSTRATED PARTS BREAKDOWN




MASTER ELECTRIC HEATERS B 9 IT

Pos.	Description	Code NR
1	TOP COVER	4165.038
2	CONTROL BASE	4165.039
3	DEFLECTOR	4165.040
4	SIDE PANELS	4165.041
5	FRONT PANEL	4165.042
6	GRILL	4165.043
7	BOTTOM PANEL	4165.044
8	KNOB	4165.007
9	RESET LEVER	4165.008
10	TEMP LIMITER SUPPORT	4165.009
11	TEMP LIMITER	4165.010
12	THERMOSTAT	4165.029
13	SWITCH	4165.030
14	ELEMENT	4165.045
15	FAN	4165.046
16	ELECTRIC MOTOR	4165.047
17	HANDLE	4165.048
18	PLUG	4160.102
19	RELAY	4165.035
20	RUBBER SUPPORT	4165.036
21	SEPARATOR	4165.049
22	OVERHEAT SENSOR	4165.020

MASTER ELECTRIC HEATERS


MODEL B 15 IT

ILLUSTRATED PARTS BREAKDOWN



MASTER ELECTRIC HEATERS B 15 IT

Pos.	Description	Code NR
1	TOP COVER	4165.050
2	CONTROL BASE	4165.051
3	DEFLECTOR	4165.052
4	SIDE PANELS	4165.053
5	FRONT PANEL	4165.054
6	GRILL	4165.055
7	BOTTOM PANEL	4165.056
8	KNOB	4165.007
9	RESET LEVER	4165.008
10	TEMP LIMITER SUPPORT	4165.009
11	TEMP LIMITER	4165.010
12	THERMOSTAT	4165.029
13	SWITCH	4165.030
14	ELEMENT	4165.057
15	FAN	4165.058
16	ELECTRIC MOTOR	4165.059
17	HANDLE	4165.060
18	PLUG	4160.103
19	RELAY	4165.035
20	RUBBER SUPPORT	4165.036
21	SEPARATOR	4165.061
22	OVERHEAT SENSOR	4165.020
23	TERMINAL BOARD	4165.062



MASTER ELECTRIC HEATERS B 22 IT

Pos.	Description	Code NR
1	TOP COVER	4165.178
2	CONTROL BASE	4165.179
3	DEFLECTOR	4165.180
4	SIDE PANELS	4165.181
5	FRONT PANEL	4165.182
6	GRILL	4165.183
7	BOTTOM PANEL	4165.184
8	KNOB	4165.007
9	TEMP LIMITER SUPPORT	4165.009
10	RESET LEVER	4165.008
11	TEMP LIMITER	4165.185
12	THERMOSTAT	4165.029
13	SWITCH	4165.030
14	ELEMENT	4165.186
15	ELECTRIC MIOTOR	4165.187
16	RELAY	4165.188
17	HANDLE	4165.189
18	PLUG	4165.190
19	TERMINAL BOARD	4165.191
20	RUBBER SUPPORT	4165.036
21	SEPARATOR	4165.192
22	OVERHEAT SENSOR	4165.020